

C43 Key operation

PRESS METHOD	Normal Mode	Numeric Entry	Alpha Entry
<–	CLX	Backspace	Backspace
<– Double press	DROP		
<– Long press, 1st release	CLSTK Clear stack	CLN Clear Numeric Entry	CLA Clear Alpha Entry
<– Long press, 2nd release	NOP	NOP	NOP
EXIT	Exit menu to previous or blank screen	ENTER without duplication	ENTER without duplication
EXIT Long press, 1st release	Exit menus to blank screen Clear HEX mode	ENTER without duplication Exit menus to blank screen Clear HEX mode.	ENTER without duplication Exit menus to blank screen Clear HEX mode.
EXIT Long press, 2nd release	NOP	NOP	NOP
$\Sigma+ 1/x \sqrt{x} \dots \text{TAN}$	$\Sigma+ 1/x \sqrt{x} \dots \text{TAN}$	$\Sigma+ 1/x \sqrt{x} \dots \text{TAN}$	A .. L
$\Sigma+ 1/x \sqrt{x} \dots \text{TAN}$ Long press, 1st release	f-function >l y^x x^2 ... ATAN	f-function >l y^x x^2 ... ATAN	A .. L
$\Sigma+ 1/x \sqrt{x} \dots \text{TAN}$ Long press, 2nd release	g-function ab/c # .ms ... RTN	g-function ab/c # .ms ... RTN	A .. L
$\Sigma+ 1/x \sqrt{x} \dots \text{TAN}$ Long press, 3rd release	NOP	NOP	NOP
ENTER	ENTER	ENTER	ENTER
ENTER Long press, 1st release	COMPLEX	COMPLEX	NOP
ENTER Long press, 2nd release	NOP	NOP	–
x<>y	x<>y	x<>y	M
x<>y Long press, 1st release	LSTx	LSTx	NOP
x<>y Long press, 2nd release	NOP	NOP	–
XEQ	XEQ	XEQ	F
XEQ Long press, 1st release	XXEQ	XXEQ	F
XEQ Long press, 2nd release	x th root y	x th root y	F
XEQ Long press, 3rd release	>POLAR	>POLAR	F
XEQ Long press, 4th release	NOP	NOP	F

PRESS METHOD	Normal Mode	Numeric Entry	Alpha Entry
FN1..FN6	FN1..FN6	FN1..FN6	FN1..FN6
FN1..FN6 Long press, 1st release	f(FN1..FN6)	f(FN1..FN6)	f(FN1..FN6)
FN1..FN6 Long press, 2nd release	g(FN1..FN6)	g(FN1..FN6)	g(FN1..FN6)
FN1..FN6 double press (if option G2TAP is set)	g(FN1..FN6)	g(FN1..FN6)	—
GOLD	f-shift		
GOLD Long press, 1st release	g-shift		
GOLD Long press, timeout	Home		
GOLD double press	g-shift		
GOLD triple press	Pop on/off HOME		

UNMARKED FUNCTIONS	Normal Mode	Numeric Entry	Alpha Entry
FN1 .. FN6 when no menu	f-shift of the top row, (including USER mode)		—
FN1 .. FN6 when no menu, double press	g-shift of the top row, (inclusive USER mode)		—
FN1 .. FN6 when no menu, long press any release			
f[Up] and f[Dn]	—	—	Caps lock up/down
g[Dn]	—	—	Caps lock toggle
f[A] & g[+]	—	—	ALPHA INTL
f[B]	—	—	#
f[C]	—	—	√
g[0] and g[Up]	—	—	ALPHA HOME
g[.]	—	—	ALPHA dot
g[R/S]	—	—	ALPHA math
R/S	—	—	/